

The Science of Paddling Part 3: The Rough Stuff

by Shawn Burke, Ph.D.

I watched a C-2 paddler with some curiosity as I tried to wipe the sleep from my eyes this past Memorial Day at Lakefront Park. He was alternately spraying a clear liquid on the bottom of his pro boat, and then madly buffing it. I thought he might be practicing some new way of warming up before the annual General Clinton 70-miler. I learned instead that the he hoped to make his boat faster by coating it with this “liquid speed.”

I asked about all of the scratches on the hull, and if perhaps they might slow him down a bit. He admitted that there wasn’t much he could do about those on race morning. But he fervently believed that the magic goo he was applying to the bottom of the hull would more than compensate for the scratches.

Back in the day I spent a couple of years of graduate school doing research at a water tunnel¹, exploring novel techniques for drag reduction. And I know that in certain cases liquid polymers (and even air bubbles) can reduce hull drag – more on that later. But these exotic techniques don’t work in the way that C-2 paddler hoped his hull polish would work. In light of some basic hydrodynamics – which is the study of fluid flow – the more pertinent question was how much of a penalty he and his partner were going to pay for all of those scratches in their hull.

The biggest misconception people have about waxes, polishes, and other sources of “liquid speed” is that they somehow allow their hulls to slip through the water faster. Or that by some magic water won’t “stick” to the hulls as easily if they are so treated. I’m sorry to burst




Figure 1: Water flow beneath a hull.

¹ Think wind tunnel, but filled with water.

anyone's bubble, but nothing could be further from the truth. There are *other* possible benefits from polishes, and we'll address those later. But in terms of making a boat more "slippery" in the water, well, not so much. In order to understand why, let's look at what happens as water flows over our hulls.

Consider the flow of water along a hull as depicted in Figure 1. In this figure the boat is moving from left-to-right in quiet water. We'll assume that the boat is up to speed and traveling at a steady rate. We'll also adopt a paddler's frame of reference, where we think of the water as flowing past the hull, rather than the hull past the water. The physics are a easier to understand that way.

As water approaches the hull in the water molecules are free to move anywhere they want. When they first encounter the boat, something interesting happens: the water molecules that contact the hull actually stick. No kidding! Right at the hull surface, the water molecules and the hull move together. Since we've adopted a boat-centric frame of reference, this means the water right at the hull's surface has zero velocity with respect to the hull. This is called the "no slip condition." The no slip condition holds whether the hull is made of Kevlar, carbon fiber, wood, aluminum, or anything else for that matter. And it is true whether the hull has been coated with "liquid speed," a UV protectant, carnauba wax, or slime from your last paddling session. In all of these cases, the relative speed between the hull, and the water in contact with the hull, is zero. Period.

Now we know that water flows past the hull as we paddle. So what happens to the water that isn't in contact with the hull, but is instead "close" to it? This is where the concept of a boundary layer comes into play. And this is where all of the friction drag comes from that is constantly trying to slow you down.




Figure 2: Boundary Layers.

The no slip condition requires the water's relative speed at the hull to be zero. The so-called "free stream" speed of water far away from the hull must equal your hull speed. Consequently, there is a variation or "gradient" in the water's relative velocity as we move away from the hull's surface until the

water's velocity equals the hull speed. The region where this gradient exists is called a "boundary layer." Boundary layers are illustrated in Figure 2 for so-called "laminar" and "turbulent" cases.

A laminar boundary layer develops near the front of the boat. The water impinging on the hull travels uniformly in this case. If you injected a colored dye in the water there you'd see that the dye moves along the hull in nice, parallel lines, hence the term "laminar" (like "laminations"). The laminar boundary layer depicted in Figure 2 has a fairly gradual gradient in the water's speed as you move away from the hull. The "sharpness" of this gradient is indicative of the frictional forces on the hull. The more gradual gradient in the laminar case reflects lower shear stress on the hull, which means lower frictional drag. In fact, if the flow over the entire hull was laminar, the frictional drag would be greatly reduced, and you'd go faster.

Unfortunately, laminar boundary layers are sensitive beasts. Think of a laminar boundary layer as being a little "channel" of water next to the hull. Inside this channel there is not only smoothly-flowing water, but also tiny pressure waves that aren't all that different from sound waves. These pressure waves – called "Tolmein-Schlichting," or "TS" waves – travel inside the laminar boundary layer in the direction of flow, e.g. from the front of the hull towards the back. TS waves are driven by small disturbances in the upstream flow, like those found when paddling in swirly or turbulent rivers.

The TS waves differ from ordinary sound waves in one very important respect: they grow in amplitude as they travel. After they travel a certain distance, they will have grown in amplitude enough that they start to disrupt the laminar boundary layer's order. The nice parallel streamlines of the laminar flow start to wiggle and distort, and become disorganized. At this point the boundary layer is starting to transition from laminar to turbulent, hence the "transition region" shown in Figure 1.

The location on the hull at which transition occurs is determined by the speed of the hull, and the viscosity of water. If we represent the hull speed as U , and the (kinematic) viscosity of water as ν , then the distance L from the front stem of the hull at which the flow becomes turbulent is approximated by the following equation:

$$\frac{UL}{\nu} \approx 1 \times 10^6$$

The expression on the left hand side of this equation is called the Reynolds number, and is often written as "Re." So, when the Reynolds number equals approximately 1,000,000 the flow over the hull becomes turbulent. For a C-1 racing at 6.3 mph (2.8 m/s) in 68F (20C) water, transition occurs a mere 14 inches (35.4 cm) from the front of the boat. Since a USCA C-1 Cruiser is typically 18'6" long, we see that the flow over the vast majority of the hull is turbulent. And if the upstream disturbances in the flow of water are large, perhaps due to whitewater eddies or the wake of a boat you are drafting, then transition will occur even closer to the front stem of the boat.

Once the flow is turbulent, there are no longer any nice, orderly streamlines inside the boundary layer. Instead, the flow becomes chaotic, and highly three-dimensional. Also, the velocity gradient inside the now turbulent boundary layer becomes sharper, as depicted in Figure 2. This reflects the fact that the frictional forces on the hull are larger. And the boundary layer itself becomes thicker, as you are putting more of your precious paddling energy into generating turbulence. Bummer! While there are ways to extend the region over which the flow over a hull is laminar, they tend to involve fairly impractical measures like generating out-of-phase sound waves ahead of the hull (as demonstrated by my grad school office mate Chuck Gedney in his Ph.D. thesis), or selectively heating the hull surface (as demonstrated by Dan Nosenchuck), to interfere with the TS waves' growth. Even then, transition is delayed by at most ~50%, under ideal laboratory conditions. So when it comes to friction drag, you can't win, you can't break even, and you can't get out of the game.

Now the no-slip condition, boundary layer transition, and turbulence are going to be there whether you coat your hull in magic goo or not. But are there any things you can do to make your boat go faster? Aside from buying a faster hull shape (and more training), the first thing to consider is the condition of your hull. Many of us who paddle on shallow rivers have had one or more close encounters with logs and rocks. The resulting scratches are a concern. But should they be?

It is well known that most minor imperfections in a hull's smoothness will slightly increase viscous drag, on the order of a couple percent. At the other extreme, a group of students at the University of Michigan took an aluminum canoe, bludgeoned it with sledgehammers all along its length, and measured the resulting increase in drag force in a towing tank. The amply distorted hull exhibited about a 6% increase in total drag; so how bad can *your* hull be? And keep in mind the fact that viscous drag is only one component of the total drag force exerted on a hull as you paddle it, as shown in Figure 3. At racing speeds viscous drag will be overshadowed by form drag and wave drag effects, which are properties of the hull's shape and the weight of the boat and paddlers. So reducing a 1% increase in viscous drag by polishing a hull will result in a fraction of a percent decrease on total drag.




Figure 3: Drag forces vs. speed.

But how rough is rough? Is there a rule of thumb regarding hull roughness for those of us who really obsess about our hulls? Well of course!

Even though the flow over 95% of our hulls is turbulent, there is a thin layer immediately adjacent to the hull's surface that is laminar, no matter what. This "laminar sublayer" exists because there is a difference between molecular diffusion and the propagation of vorticity – in other words, serious

techno babble. But suffice it to say that *as long as the height of any surface roughness is small relative to the thickness of this thin laminar sublayer, then the hull will behave as if it is hydrodynamically smooth.*

The laminar sublayer thickness δ_l is approximated by

$$\frac{\delta_l}{x} = 103 \times (\text{Re}_x)^{-\frac{9}{10}}$$

where Re_x is the Reynolds number cited above, but now based on the distance x from the bow. Figure 4 is a plot of the sublayer thickness along the hull for an 18.5-foot racing canoe running at 6.3 mph (2.8m/s) in 68F (20C) fresh water. As you'll note from the plot, the sublayer thickness varies from about 5 thousandths of an inch near the bow to around 8 thousandths of an inch near the stern. So to ensure that your hull is "hydrodynamically smooth," make sure it is no rougher than the average grain size of 120 grit sandpaper. Roughness greater than that will introduce more turbulence into the boundary layer, and a (tiny) increase in overall drag.




Figure 4: Sublayer Thickness vs. Distance Along the Hull.

So where should you focus your energy and resources to reduce friction drag, if anywhere? Certainly a scratched and rough hull will foul more easily, and deep scratches should be repaired if for nothing else than to prevent moisture penetration into the underlying fibers of a Kevlar or carbon lay-up. Those are reasons enough to keep a hull in good repair. And if you really want to do some polishing, and the polish fills or grinds down in any superficial scratches, then there will be a *tiny* decrease in frictional drag. This will most important in the leading couple of feet of the hull, since small surface imperfections there can help destabilize a laminar boundary layer and lead to an even earlier transition to turbulence. So by all means polish the bow and the front meter or so of the hull, and keep the rest smoother than around

0.007". But as to employing "liquid speed," the chief benefactor there may lie between your ears. If you feel that it makes you paddle faster, you probably will.

Addendum – Novel Drag Reduction Techniques

In the 1980s there were several studies that characterized exotic approaches to turbulent drag reduction, such as compliant skins, injecting long-chain polymers or air bubbles into the flow, and "scoring" surfaces along the direction of flow. In summary:

- The jury is still out on whether compliant hull surfaces reduce drag. But it was an interesting technology to explore, and funded two years of graduate school for me.
- Injecting air bubbles into a boundary layer can have a huge effect on drag. In essence, you are encasing the hull in a thin envelope of air, so now you only have to counteract the drag force arising from moving the hull through air, rather than through water – much less. Rumor has it that this technology has been incorporated into high-speed torpedoes. Incorporating an air injection system into racing hulls would entail a lot of equipment, weight, and space, so it's not very practical to our needs.
- Injecting long-chain polymers into a turbulent boundary layer can measurably reduce drag. It apparently works by dampening the growth of turbulence in the cross-stream direction. And by "long-chain polymers," think of something like cooking oil. In order for this to work you have to controllably inject thin streams of it into the boundary layer the entire time you are under way. I'm not sure I'll be seeing pit stops at the General Clinton where crews are re-supplying water, food, and canola oil.
- 3M used to sell a type of polymer sheeting that had parallel, triangular grooves. The grooves were 6 thousandths of an inch tall, spaced 6 thousandths of an inch apart. The sheeting was adhered to a hull with the grooves aligned in the direction of flow. Under certain conditions, surfaces with this "ribbed" covering can experience a drop in viscous drag ranging from 2 to 8 percent. This material was tested on rowing shells. Unfortunately, while there seemed to be some initial effect in reducing drag, the next day the effect disappeared. This may likely be attributable to surface fouling between uses. Remember, a 6 thousandth of an inch feature is quite small, easily damaged, and easily filled with river slime.